

Rubberflex Maintenance Instructions

A. CLEANING

1. Keep floor clean of dirt and debris by daily sweeping and vacuuming.
2. Occasional damp mopping using a mild cleaning agent (e.g., Simply Green) will maintain the beauty of the surface.
3. On rare occasions when the floor is extremely soiled, a cleaning agent made exclusively for rubber by Taski-Profy can be used. Follow the manufacturer's instructions on the cleaning agent. This product can be purchased from a janitorial supply dealer.
4. Rubberflex installed outdoors may be cleaned with a mild detergent, nylon bristle scrub brush and water. Ensure all soap residue is rinsed from Rubberflex before allowing to dry. Power washing using medium pressure nozzles may also be utilized for outdoor installations.

B. GENERAL PRECAUTIONS

1. Care should be exercised when moving/relocating equipment over Rubberflex flooring installations so as to prevent damage to the new floor.
2. Do not scrub or strip fully adhered floors until at least 4 or 5 days after installation so that the Rubberflex flooring will have become well-seated in the adhesive.
3. The use of pads, wide casters/rollers, furniture/equipment cups, may prevent excessive indentation.
4. When moving heavy weight training machines over loose-laid Rubberflex rolls or tiles, plywood sheets should be placed over the floor area. Heavy machinery rolled or dragged over the flooring can create separation of double sided taped installations.

NOTE: The performance and guarantee of the products used in preparation, testing, installation and maintenance of Rubberflex, during and after installation, remain with the manufacturer of said product and not Centaur Floor Systems.